

Installation, Operation & Maintenance Instruction (Flanged End Ball Valves)

1. Scope: This instruction applies to 2-PC Body Flanged End Ball Valves.

Mounting Pad: 200966 and 200969 DN15 to DN100

Direct Mount: 200955, 200960, 200961, 200963, 200964, 200965, 200968, 201968 and 200966/200969 DN125 and above

2. Warning (Restrictions on Use)

- a. Temperature and Pressure Limit
 - The normal maximum operating pressure at maximum or minimum operating temperature is shown on nameplate.
 - The operating temperature is within -50°C to 180°C for TFM1600 seat and sealing. Other seat and sealing operating temperature shall be checked with TUNING Fluid Solutions.
 - The nominal pressure (PN) rating describes maximum working pressure in cold operating temperature (e.g. PN40 describes maximum working pressure 40 bar at $-39^{\circ}\text{C} \sim 40^{\circ}\text{C}$).
- b. No throttling operation
 - Don't leave the ball partly open (throttling operation) where the pressure drop and/or flow rate damage to the valve seats and/or ball.

3. Installation

- a. Remove the protective cover on both flange end, and clean or flush the valve in fully open position.
- b. Prior to mounting, flush and clean the pipeline and valve to remove all accumulated extraneous matters.
- c. During the handling process, do not use the valve stem or handle (wheel) as a fulcrum for the lifting cable to avoid collapse and accidental injury.
- d. The valve may be fitted in any position and direction in the pipeline.
- e. Make sure the pipeline at the installation point is not bent down and/or tension, use a pipe hanger or supports for the purpose to eliminate any deviation of the piping.
- f. Tighten the flange bolt crosswise using the stipulated torque, to see below table A.

Table A: Torque figure for Flange Bolt tighten

Material & Unit Bolt Size	Alloy Steel (B7)		Stainless Steel	
	IN-LB	N.M	IN-LB	N.M
5/16-18UNC/M8	240	27.2	100	11.3
3/8-16UNC	420	47.5	160	18.1
7/16-14UNC/M10	660	74.7	280	31.7
1/2-13UNC/M12	1000	113.2	400	45.3
9/16-12UNC/M14	1460	165.2	580	65.6
5/8-11UNC/M16	2010	227.4	800	90.5
3/4-10UNC/M20	3580	405.1	1400	158.4
7/8-9UNC/M22	5770	652.9	2250	254.6
1-8UNC/M24	8650	978.7	3250	367.7
1,1/8-8UNC/M28	12700	1437.0	4000	452.6

Table B: Torque figure for Stem Nut tighten

Valve Size	IN-LB	N.M
1/2 "	70~80	8.0~9.0
3/4 "	70~80	8.0~9.0
1 "	90~100	9.0~11.3
1-1/4 "	90~100	9.0~11.3
1-1/2 "	140~160	15.8~18.1
2 "	140~160	15.8~18.1
2-1/2 "	180~200	20.4~22.6
3 "	180~200	20.4~22.6
4 "	250~270	28.3~30.6
5 " ~ 6 "	300~350	34.0~39.6
8 "	580~630	65.6~71.3
10 "	800~850	90.5~96.2

4. Operation and Use

- a. Flush the ball valve and pipeline thoroughly again before operation.
- b. The operation of the valve consists of turning the stem (by manual or automated means) 1/4 turn (90°) clockwise to close, and 1/4 turn counter-clockwise to open.
- c. When the handle (if used) and/or stem flats or groove are in line with the pipe, the valve is open.

Installation, Operation & Maintenance Instruction (Flanged End Ball Valves)

- d. Operating torque requirements will vary depending on the length of time between cycles, media in the system, line pressure and type of valve seat. The figures in the following table C are based on PTFE seats with clean water as the media.

Table C: Torque Value

△ P difference-pressure

unit: inch-lb/nm

Size\△P		75Psi	150Psi	300Psi	700Psi
		5Bar	10Bar	20Bar	50Bar
1/2 "	DN15	35/4.0	35/4.0	35/4.0	35/4.0
3/4 "	DN20	46/5.2	46/5.2	46/5.2	46/5.2
1 "	DN25	77/8.7	77/8.7	77/8.7	84/9.5
1-1/4 "	DN32	91/10.3	91/10.3	105/11.9	119/13.4
1-1/2 "	DN40	126/14.3	126/14.3	168/19.0	196/22.2
2 "	DN50	196/22.2	231/26.1	252/28.5	287/32.5
2-1/2 "	DN65	315/35.6	364/41.2	406/45.9	504/57.1
3 "	DN80	434/49.1	504/57.1	560/63.4	805/91.1
4 "	DN100	700/79.2	840/95.1	1050/118.8	1400/158.4
5 "	DN125	1520/171.2	1600/180.8	1840/208	2560/288.8
6 "	DN150	2000/225.6	2160/244	2400/271.2	3600/406.4
8 "	DN200	2800/316	3040/343.2	3440/388	5280/596
10 "	DN250	5840/659.2	6800/767.2	7760/876	11360/1282.4

5. Maintenance

Long life and maintenance-free of valves can be maintained under normal working conditions and in accordance with pressure/temperature and corrosion data chart.

Warning:

- ★ Ball Valves can trap pressurized fluids in the Ball cavity when closed position.
- ★ Prior to maintenance, relieve the line pressure and put ball in open position.

a. Re-tighten packing

- Should a leakage occur at the gland packing, retighten the stem (gland) nut (13).
- Take care that the stem nut (13) are not tighten too much. Normally the leakage can be stopped by simply turning the stem nut (13) by 30° to 60°.


b. Replacement of seats and seals.

Disassembly

- Place the valve in half-open position and flush the line to remove any hazardous material from the valve body.
- Place the valve in close position, remove both counter flange bolts & nuts and lift valve from line.
- Remove handle nut (15), handle (16) or actuator set, stop-lock-cap (14), stem nut (13), Belleville washer (12), gland (11), bush(10).
- Remove body bolt (5) or stud nut to allow end cap (2), separated from body (1), remove body gasket (19).
- Make sure ball in "Close" position, thus the ball (3) can be taken out easily from body, then take out body ball seat.
- Push stem (6) down into the body cavity and remove, then remove stem seal-ring (8), V-stem packing (9) from the body.

Installation, Operation & Maintenance Instruction (Flanged End Ball Valves)

Caution: Use care to avoid scratching the surface of stem and packing chamber.



Reassembly

- Reassembly process is reverse sequence of disassembly.
- Clean and inspect all parts, full replacement of all soft parts (seats and seals) are strongly recommended.
- Tighten the body bolt (5) crosswise using the stipulated torque figure (see table A)
- Tighten the stem nut (13) using the table B stipulated torque figure.
- Cycle the valve slowly with gentle back and forth motion to build gradually to full quarter turn.
- If possible, test the valve before placing it back to line for service.